Southwire™

FBCVBR-15A-KIT / FBCVSS-15A-KIT / FBCVBK-15A-KIT

INSTALLATION INSTRUCTIONS

INSTRUCCIONES DE INSTALACIÓN

WARNING: IMPROPER INSTALLATION OF AN ELECTRICAL DEVICE CAN CAUSE SERIOUS INJURY OR DEATH. THIS PRODUCT SHOULD ONLY BE INSTALLED BY A QUALIFIED PROFESSIONAL.

TURN OFF POWER TO OUTLET AT THE BREAKER.
INSTALL ACCORDING TO LOCAL AND NATIONAL ELECTRICAL CODES.

1. Ensure that there is sufficient depth and space below the sub floor.
2. Trace box opening on the floor and cut the floor.
   WARNING: DO NOT OVERCUT FLOOR OPENING!
3. Insert box through opening. Secure box to floor with supplied wood screws through box adapter. Pre-drill 4 holes with 1/8" drill bit.
4. Install receptacle.
   a. CAUTION: Use Copper conductors only; 15A, 14 AWG to12 AWG.
   b. Remove insulations from the conductors 5/8".
   c. Connect hot (black) wire to brass screws.
   d. Connect neutral (white) wire to silver screws.
   e. Connect ground (green or bare) wire to green ground screw.
5. Install gasket between cover and floor.
6. Attach cover to box adapter using supplied screws.

ADVERTENCIA: LA INSTALACIÓN INCORRECTA DE UN DISPOSITIVO ELÉCTRICO PUEDE CAUSAR LESIONES GRAVES O LA MUERTE. ESTE PRODUCTO SÓLO DEBE SER INSTALADO POR UN PROFESIONAL CALIFICADO.

DESCONECTA LA ENERGÍA ELÉCTRICA DEL TOMACORRIENTES EN EL PANEL DE INTERRUPTORES. INSTALA DE ACUERDO CON LOS CÓDIGOS ELÉCTRICOS LOCALES Y NACIONALES.

1. Asegúrate de que haya suficiente profundidad y espacio debajo del contrapiso.
2. Traza la abertura de la caja en el piso y corta el piso.
   ADVERTENCIA: ¡NO CORTES EN EXCESO LA ABERTURA DEL PISO!
3. Inserta la caja a través de la abertura. Asegura la caja al piso con los tornillos para madera incluidos a través del adaptador de caja. Pretaladra 4 orificios con una broca de 1/8".
4. Instala el receptáculo.
   a. CUIDADO: Utiliza únicamente conductores de cobre; 15 A, 14 AWG a 12 AWG.
   b. Retira 5/8" de los aislamientos de los conductores.
   c. Conecta el cable con corriente (negro) a los tornillos de latón.
   d. Conecta el cable neutro (blanco) a los tornillos plateados.
   e. Conecta el cable de conexión a tierra (verde o pelado) al tornillo verde de conexión a tierra.
5. Instala la junta entre la cubierta y el piso.
6. Fija la cubierta al adaptador de caja utilizando los tornillos incluidos.

Distributed by/Distribué par:
Southwire Company, LLC.
One Southwire Drive
Carrollton, GA 30119

Made in China / Hecho en China
©2026 Southwire Company, LLC.
All rights reserved.Tous droits réservés.