

T8 BALLAST COMPATIBLE LINEAR LAMP INSTALLATION INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS!



WARNING


- Make all electrical and ground connections in accordance with local codes or the National Electrical Code. If you are not familiar with these codes and requirements, consult a qualified electrician. This Professional should be familiar with the construction and operation of this product and hazards involved. Failure to do so may result in serious personal injury.
- To reduce the risk of fire, electric shock, personal injury, or property damage, please read and follow all safety instructions. If you do not understand these instructions or if any additional information is required, contact your local Topaz representative. Retain these instructions for maintenance reference.
- Do not exceed the allowed supply voltage marked on the luminaire label information.
- Disconnect power at the circuit breaker panel before any installation.




CAUTION

- Do not expose wire to any sharp objects such as sheet metal to prevent wiring damage or abrasion.
- While the light is on, please avoid direct eye exposure.
- Combustible material should be kept away from fixture/LENS.
- Do not make or alter any open holes in any enclosure or any electrical component during installation.
- Do not use when the enclosure is damaged or broken in any way.

Single Lamp Wiring:




Two Lamp Wiring:



Item:
L4T8E/8xx/13/F-70





T8 BALLAST COMPATIBLE LINEAR LAMP INSTALLATION INSTRUCTIONS



Installation Instructions:



1. Turn OFF power to the luminaire.

2. Remove diffuser (if provided).




3. Remove the existing fluorescent lamps from the luminaire.

4. Put on LED T8 Tube (one for each fluorescent lamp removed).



5. Replace diffuser (if removed in step 2)

6. Turn ON power to the luminaire.



****NOTE: THESE INSTRUCTIONS DO NOT ADDRESS ALL PERMUTATIONS THAT MAY EXIST IN INSTALLATION, MAINTENANCE, AND OPERATING ENVIRONMENT.**