



INSTALLATION OF WIRES INTO INDUSTRIAL GRIPit™ PULLING DEVICE

- **Industrial GRIPit™ pulling devices come in 5 different staggered lengths to prevent them from binding in conduit during the cable pull.**
 - **Industrial GRIPit™ pulling devices can be used with circuit sized wires 10awg and up.**
 - **Industrial GRIPit™ pulling devices can accommodate 7 wires.**
 - **Kits are available in packages of 5 to allow for pulling of up to 35 circuit sized wires at one time.**
 - **Can be used in conduit sizes 1-1/4" and up.**
-
- 1. Select one wire and insert into bottom triangle.**
 - 2. Bend wire over ensuring a minimum of 1" is protruding through triangle.**
 - 3. Repeat this process until all 7 triangles are full.**
 - 4. Once complete, use electrical tape to secure all circuit wires to Industrial GRIPit™ pulling device (Optional).**
 - 5. Connect lanyard(s) of Industrial GRIPit™ pulling device to pulling eye of rope with a rated swivel or clevis.**



Southwire™

TOOLS & EQUIPMENT

INSTALLATION OF WIRES INTO INDUSTRIAL GRIPit™



1.



2.



3.



4.



5.